Getting started with your new Fujitsu LifeBook® T5010 Tablet PC

This convenient guide will lead you through the start-up process in eight easy steps and will also offer some valuable tips.



1. What's in the Box

Check to see that all of the following are in the box:

- ❍ LifeBook T Series Tablet PC
- ❍ AC adapter and power cable
- ❍ Lithium ion battery (pre-installed)
- ❍ Pen-kit including one pen, five additional pen tips, and tip replacement tool
- ❍ Drivers and Application CD
- ❍ Warranty Terms & Conditions Booklet
- ❍ Microsoft associated discs
- ❍ Trusted Platform Module Application disc
- ❍ Pen tether
- ❍ Restore disc
- ❍ Microfiber Cleaning Cloth
- ❍ Third party application disc

2. Turn on Your Tablet PC

- Plug the AC adapter into your Tablet PC.
- Plug the power cord into the AC adapter.
- Connect the power cord to an electrical outlet.
- Connect phone cord or Ethernet cable to your Tablet PC and to a wall jack.
- Press the Suspend/Resume switch to turn on the Tablet PC.
- The Tablet PC is now on and the battery is being charged.
- The Tablet PC will begin a power-on self test.
- Once the self test is successfully completed, the operating system will begin the initialization process.

3. Register

For Genuine Microsoft® Windows® XP Tablet PC: After the operating system has initialized, accept the Microsoft® Windows® Licensing Agreement and the Fujitsu End User License Agreement to proceed. Then enter the information as prompted to personalize your notebook and configure your modem* to dial.

For Genuine Windows Vista™: Accept the Microsoft® Windows® Licensing Agreement and the Fujitsu End User License Agreement to proceed. Select your User ID and Password during the "Welcome Screen." Keep a record of your User ID and password stored in a secure place. **THE SCREEN WILL GO DARK FOR APPROXIMATELY TWO MINUTES.** Do not attempt to turn power on or off during this stage.

** Wireless WAN model does not come with modem.*

4. Installing Click Me!

- Check to be sure the wireless radio switch is on.

For Genuine Microsoft® Windows® XP Tablet PC: The first time you boot up your system, you will see an icon called Click Me! in the Start menu.

For Genuine Windows Vista™: In addition to an icon on the desktop, a dialog box will automatically open that prompts you to run Click Me!. Please proceed with ClickMe! to complete the system initial installation.

- When you click the Click Me! icon, your system will automatically build the icon tray in the bottom right of the screen. These icons provide links to utilities that you will frequently access.

5. Register Your Tablet PC

Register your Tablet PC with Fujitsu Service and Support via our website (us.fujitsu.com/computers).



Security Panel Button Functions (System State—pre-boot or resuming from suspend)					
	Security Button 1	Security Button 2	Security Button 3	Security Button 4	Security Enter Button
Pre-logon Tablet PC Button Functions (System State – pre-logon (Windows logon screen is displayed)					
Notebook Function	<Tab>	<Enter>	Rotate Screen	Used to invoke secondary function	Ctl+Alt+Del Button
Secondary Functions (Fn+ Button)	<Shift> <Tab>	<Escape>	None	None	None
Post-logon Tablet PC Button Functions (System State – pre-logon (Windows logon screen is displayed)					
Primary Notebook Function	Page Down	Page up	Rotate Screen	Secondary function Selection	Ctl+Alt+ Del Button
Secondary Functions (Fn+ Button)	User-defined Application A (Default = Calculator)	User-Defined Application B (Default = MS Journal)	Display Switching: 1. LED only 2. CRT only 3. Dual Display	Fujitsu Menu Utility	None

Table 1

LEFT PANEL



RIGHT PANEL



BACK PANEL



LED Indicators

Button Icon and Name (Primary)

- Power
- External Power
- Optical/Hard Drive Access
- 1 Battery 1 Charging
- 1 Battery 1 Level
- 2 Battery 2 Charging
- 2 Battery 2 Level
- 1 NumLk
- A CapsLk
- ScrLk
- Security

LifeBook Security/ Tablet PC Buttons

Please refer to Table 1
The five security/Tablet PC buttons are located on the bottom right-hand side of the display when it is configured to be used as a notebook.

Security functions: All five buttons are used when implementing security functions. Four of the buttons are used to enter the password, and the fifth is used as an Enter button.

Tablet PC functions: The Tablet PC buttons have a number of functions, depending upon the state of the system: pre-logon state or post-logon state.

The system is pre-logon when the Windows logon screen is displayed; the system is post-logon when the Windows desktop is displayed. All five of the buttons have primary functions. Several of the buttons also have secondary functions (see chart) when used as application buttons and are activated by pressing the Function (Fn) button while pressing the application button. In post logon, the secondary functions of the Application A and B buttons can be changed to launch any application. See User's Guide for more information about using the Security/Application Buttons.

Drivers

Look for the latest drivers on the Drivers and Applications CD. Right-click the FDU icon and select "update", or go to us.fujitsu.com/computers.

6. Convert from Notebook to Tablet

- Lift the display until it is perpendicular to the keyboard.
- Carefully rotate the display clockwise or counter clockwise until it is facing backwards.
- Holding the top edge of the display panel, push it down until it is nearly on top of the keyboard.
- Push the display latch down (the latch will pivot clockwise). The top latch disappears, and the bottom latch appears (A).
- Holding the latch down, gently push down on the display until the latch engages.
- To return to a notebook configuration, press the latch release button, and raise the screen until it is perpendicular to the keyboard. Be sure to turn the display in the direction indicated by the display rotation light and push the display latch so it faces forward (B).

7. Installing Additional Software

- Load the Drivers and Applications disc to check for the latest versions of pre-installed drivers and applications. Install additional applications not pre-installed on your system, such as CyberLink Power Director and Make Disc (on select models).

8. Additional instructions for WWAN (Wireless Wide Area Network) model

- If your system comes with a built-in Mobile Broadband module, please follow the installation and activation instructions, which are included in a separate package with your LifeBook Tablet PC.



If you have:	You will need to install the following software:
Dual-Layer Multi-Format DVD Writer	CyberLink Power Director and Make Disc

FUJITSU THE POSSIBILITIES ARE INFINITE

Popular Accessories

Docking Options
- Port replicator

Memory Options
- 1 GB SDRAM, DDR3 1066 MHz
- 2 GB SDRAM, DDR3 1066 MHz

Power Options
- AC adapter with US cord
- Main battery
- Auto airline adapter
- Modular Bay Battery
- Battery charger w/AC adapter

Storage Options
- Modular DVD/CD-RW Combo Drive
- Modular Dual-Layer Multi-Format DVD Writer
- Modular Hard Drive

Carrying Cases
- Director leather carrying case
- Diplomat carrying case
- Executive Leather Portfolio
- Convertible Bumpcase
- Modella Plus Backpack

Input Devices
- Replacement stylus set (2 pack)
- USB optical mouse

Additional Accessories
- Notebook guardian lock
- 4-in-1 PC Card Adapter
- Logitech wireless keyboard and mouse
- Screen Protector (6 pack)
- Deluxe Stylus Tether

Fujitsu extended service plans available.

Visit us.fujitsu.com/computers
to purchase any of these accessories
or to get more information.

Have questions or need help?
- Visit our website at us.fujitsu.com/computers
- Call us anytime at 1.800.8FUJITSU
- Email us at 8fujitsu@us.fujitsu.com

Want more information on Fujitsu products?
- Visit our website at www.shopfujitsu.com
- Call us anytime at 1.800.FUJITSU

Record your notebook serial number here:
Serial #_____
(see bottom of computer)

Fujitsu Computer Systems Corporation
1250 E. Arques Avenue M/S 122
Sunnyvale, CA 94085

Fujitsu, the Fujitsu logo, and LifeBook are registered trademarks of Fujitsu Limited. Microsoft, Windows and Windows Vista are registered trademarks of Microsoft Corporation. All other trademarks mentioned herein are the property of their respective owners. Product description data represents Fujitsu design objectives and is provided for comparative purposes; actual results may vary based on a variety of factors. Specifications are subject to change without notice.

©2008 Fujitsu Computer Systems Corporation. All rights reserved.

B5FJ-7971-01EN-00

Getting Started

Get Started with your LifeBook® T5010 Tablet PC

FUJITSU

THE POSSIBILITIES ARE INFINITE